

Concrete Truck Driver Hand Signals

Back up



Arm bent at elbow, hand cupped. Move arm back and forth towards the body.

Shift truck over



Outstretched arms with open hands apart, clearly indicating where the truck is to be moved.

Stop truck, bowl



Arm bent at elbow, fist with knuckles facing outwards.

Move truck forward



Outstretched arm with hand outstretched and thumb pointing upward.

Mix



Left hand palm facing up. Right hand closed, fist rotating above left.

Discharge bowl



Arm bent at elbow, rotating clockwise.

Speed up bowl



Speed up, Lift outstretched arm, palm up.

Slow down bowl



Slow down. Lower outstretched arm, palm down.

Load finished, spin out bowl



Arm bent at elbow and quickly rotating in a clockwise (discharge) direction.

No response should be made to unclear signals